Installation Manual Of PV Energy Storage Machine

list

1 Brief Introduction 4
1.1Preface 4
1.2Target Group 4
1.3Product Description 4
1.4 Safety Instructions 5
2 Safety 5
2.1 Purpose Use 5
2.2 Safety Measure 6
2.3 Symbols introduction on the energy storage machine 7
3 Product Description 8
3.1 Growatt SP series inverter 8
3.2 Label Explanation 8
3.3 Size and weight 9
3.4 The advantage of the unit of Growatt SP 10
4 Unpacking 10
5 Installation 11
5.1 Basic installation requirements 11
5.2 Installation Instructions 12
5.3Storage System Connection Mode 15
5.4 System Electrical Connection 18
5.5 Grounding 26
6 Commissioning 26
6.1 Commissioning of Energy storage machine 26
6.2 Operation modes 27
6.3 LED AND LCD'S DISPLAY 28
6.4Communication 32
7 Start-up and shut down the inverter 34
7.1Start-up the inverter 34
7.2 Disconnect the inverter 34
8 Attention of the installation environment, maintenance and cleaning 35
9 Fault removal 35
10 Manufacturer Warranty 38
11 Decommissioning 39
11.1 Dismantling the energy storage 39
11.2 Packing the energy storage machine 40
11.3 Storing energy storage machine 40
11.4 Disposing of the energy storage machine 40
12 Product specification 40
12.1 Growatt SP series energy storage machine product specification 40
12.2 DC input terminal parameter 42
12.3 Torque 42
12.4 Appendix 42

13 Certificate 43
14 Contact 43

1 Brief Introduction

1.1Preface

This manual will provide the users who use the PV Energy Storage Machine of Growatt SP Series of GROWATT NEW ENERGY TECHNOLOGY CO.LTD.SHENZHEN(Short for Growatt New Energy as below) with the detailed product information and the installation instructions. Please read this manual carefully and put this manual on some place where is convenient to installation, operation, obtain. Any modifications of Growatt new energy, we will not notify the user

1.2Target Group

The energy storage machine must be installed by professional electrical personnel who have obtained the certification of the relevant departments. Installer can install energy storage machine of Growatt SP Series rapidly and troubleshooting, build communication system through read this manual carefully. If you have any questions in the process of installation, you can login in www.growatt.com and leave some message. Or you can call our 24-hour service hotline 0755-29467281/400-833-9981.

1.3Product Description

The energy storage machine of Growatt SP Series is used to store excess energy generated by the photovoltaic cell panels in the battery, the excess energy can be sent to power grid through the energy storage machine and the inverter at night. The energy storage machine of Growatt SP Series adopts the conversion of topology in both directions, Can satisfy two kinds of work needs of charge and discharge.

Overview:



Position	Description
A	Tap on the marked area
B	LCD display screen
C	LED of status display
D	DC output
E	panel input
F	DC switch
G	Touch ground point of box
H	AC socket
I	The reserved antenna hole
J	Lead battery temperature test line and current transformer measurement line connector
K	LAN connector
L	RS232 cover board
M	battery power connecting pin
N	lithium BMS RS485 connector

1.1 Safety Instructions

1. Pease read this manual carefully before the installation, The company has the right not to quality assurance, If not according to the instructions of this manual for installation and cause equipment damage.
2. All the operation and connection please professional electrical or mechanical engineer.
3. During installation, Please don't touch the other parts within the box
4. All the electrical installation must comply with the local electrical safety standards

1.4 Safety Instructions

1）Pease read this manual carefully before the installation, The company has the right not to quality assurance, If not according to the instructions of this manual for installation and cause equipment damage.

2）All the operation and connection please professional electrical or mechanical engineer.

3）During installation, Please don't touch the other parts within the box

4）All the electrical installation must comply with the local electrical safety standards

5）If equipments needs to maintain, Please contact with local specify system installation and maintenance personnel

6）Use the equipment to combined to grid needs to obtain the permission of local power supply department

7）When install PV modules in the daytime, Installer should cover the PV modules by opaque materials, Otherwise it will be dangerous as high terminal voltage of modules in the sunshine

2 Safety

2.1 Purpose Use

The system chart of PV energy storage:



Chart 1.1

As shown above, A complete grid-connected system of PV storage consists of PV modules, storage machine, battery, PV inverter, utility grid and other components. In the PV energy storage system, energy storage machine and inverter are the key parts of component parts

Attention:

As the system refer to battery use, We must make sure ventilation of the service environment and temperature control in order to prevent the danger of battery explosion, Battery recommended installation environment must be strictly in accordance with the specification in IP20 environment, meanwhile the temperature should be control in the 0-40℃ of indoor ventilation. If the chosen PV modules needs to positive or negative ground connection, please contact with Growatt for technical support before installation.

2.2 Safety Measure

DANGER

Risk of high voltage！

- Relevant operation for professional personnel
- Please notice children, disabled, laypeople do not close
- Supervise and make sure children don't play near the installation position of energy storage machine

DANGER

Risk of burns on the parts shell of energy storage machine ！

- During the work, Cover, shell around, radiator is likely to be hot

Energy storage machine exists radiation maybe affect health !

Don't stay a long time within 20cm range from energy storage machine

Energy storage machine ground connection

Please ensure energy storage machine ground connection is reliable for make sure people's safety

2.3 Symbols introduction on the energy storage machine

symbol	description
	Electrical voltage!
	Risk of burns !
	Point of connection for grounding protection
	Direct Current(DC)
	Alternating Current(AC)
	The inverter complies with the requirements of the applicable CE guidelines

3 Product Description

3.1 Growatt SP series inverter

Marks of energy storage machine

Mark	Description	Explanation	
knock here	Tap symbol	Operation of display screen (Detailed in section 6)	
Normal Fault STATUS	Status symbol of energy storage machine	Green light on	Energy storage machine run normally, charge or discharge
		Red light on	fault state
		Red light blinking	1.Alarm state 2.Software updating

3.2 Label Explanation

Label contains the following information: The type of product,



Description of label：

the type of product	**Growatt SP2000**
Input voltage range	100-580Vdc
Max input power range of energy storage machine	3000-6000W
Max input current	30A
Max charge and discharge power	2000W
Output voltage range of discharge at night of energy storage machine	150-500Vdc
Max charge and discharge current of energy storage machine	10A
Battery voltage range	46-58Vdc
Max charge and discharge current of battery	⩽45A
Suitable battery types	Lead battery and lithium battery
Recommend battery capacity range	90-200Ah
The discharge depth control of battery	Lead battery50%DOD Lithium battery80%DOD
Discharge capacity at night	2-9kWh
Safety certification	CE
Display	LED status display LCD information display
Level of protection	IP20
Communication type	RS232/LAN/WIFI(choice)

3.3 Size and weight



Chart 3.1

	A(mm)	B(mm)	C(mm)	weight(kg)
Growatt SP 2000	482	355	166	12

3.4 The advantage of the unit of Growatt SP

Features below:

- Adapt to existing PV system with general inverter and new system
- Battery management system, To satisfy pattern of Lead battery and lithium battery
- Wide working voltage range：100V~580V。
- Easy installation。
- Max efficiency 94%。
- Satisfy RS232，WIFI wireless and LAN communication monitoring

4 Unpacking

Please check whether external damage to the goods before unpacking

After unpacking, Please check whether the unit damage or missing parts, If it is happen, Please contact with supplier.

Energy storage machine of Growatt SP series and accessories as follows:



Chart 4.1

Item	Number	Description
A	1	Energy storage machine of Growatt SP series
B	1	electric current transducer (Standard wire length 5m)
C	1	Battery temperature detection line(Standard wire length 1.5m)

D	4	M6 Setscrew
--	1	Warranty card
--	1	User Manual

Attention:

"--" don't show in the picture

5 Installation

5.1 Basic installation requirements

A The installation location must be suitable for the energy storage machine's weight for a long period time(Please refer to the specification in chapter 10 about the weight of energy storage machine)

B The installation location must conforms with dimension of energy storage machine

C Do not install the unit on structures constructed of flammable or thermo labile materials

D The Ingress Protection rate is IP65 which means the unit can be installed indoors

E Battery installation option is not far below the position of energy storage machine

F The humidity of the installation location should be 0 ~ 95%

G The ambient temperature should be -25℃ ~40 ℃

H Energy storage machine can be installed in vertical or lean back on plane, Please refer to the below



Chart 5.1

I In order to ensure machine can run normally and easy to operate, please pay attention to provide adequate space for energy storage machine, Please refer to below:



Chart 5.2

J Do not install the machine near television antenna or any other antennas and antenna cables K Don't install the machine in the living area

L Be sure that the machine is out of the children's reach

5.2 Installation Instructions

Note： Before installation, Please confirm whether it is the first install system or have already installed system after installed the inverter, If it is the first install system, Please according to the installation manual of inverter, Installing the inverter first, If not, Please installation as the following steps.

5.2.1 Installation Layout

The installation layout of energy storage machine at home as following：

The energy storage machine SP 2000 needs to install near bus position(The red line is sampling line of Sensor as below, The wire length is 5m（no more than 15m）,Installation position needs to consider distance less it),



Chart 5.3

The whole system diagram of PV online storage is as follows ：



Chart 5.4

5.2.2 Installation of energy storage machine

1. Project the machine's probably size on the wall, Make sure the drill position（As the chart 5.5a below）
2. Drill setscrew of M6 on the wall（As the chart 5.5b below）
3. Install four setscrews of M6（As the chart 5.5c below）
4. Hang the energy storage machine on the four setscrews（As the chart 5.5d below）
5.Lock the nut of setscrew（As the chart 5.5e below）
6. The whole installation has finished（As the chart 5.5f below）



a)



b)



c)



d)



e)



f)

Chart 5.5

5.3Storage System Connection Mode

5.3.1 Difference between Traditional Photovoltaic System and Storage System

Growatt SP 2000 series storage plus can be connected to single-phase grid-connected inverter to build a storage-function system. Every string can be connected to one SP 2000. If you have double MPPTs to be connected to SP 2000 respectively, every MPPT connects one will be feasible.

The traditional single-phase inverter system is shown as below:



Chart 5.6

Traditional single-phase inverter system consists of PV panels, PV inverter, load and power grid. The inverter supplies the power generated by solar panels to household load. Extra electricity will be fed to the grid when generated power is more than family load needs; otherwise inverter will get power from grid for supplement.

PV Storage System with the storage plus is shown as below:



Chart 5.7

Compared with the traditional photovoltaic system, a storage-control device SP 2000, battery cells and a sensor for information collection have been added into the Storage System (Notice: Sensor must be installed close to the grid side).

5.3.2 Storage System installation with Dual-MPPT inverter

As for connection with single MPPT inverter, you can refer to 6.4.1 for installation. When installing the storage system with dual MPPT inverter, if you just upgrade one MPPT to execute storage function, you are advised to install the Storage Plus to the MPPT which generates greater power. Installation diagram as below:



Chart 5.8

Connect one PV string to the Storage Plus, and then to one MPPT of the inverter. While connect the other PV string direct to the input terminal of the inverter.

If both MPPTs are to be upgraded to execute storage function, installation should be done as below:



Chart 5.9

Notice: During the installations above ,please pay attention to the installation position of the sensor.

5.3.3 Installation steps of Upgrading existing PV system

Steps to add the storage system into the original installed PV inverter system are shown as follow:

Step 1: If inverter is equipped with a DC switch, please turn the DC switch to Off and ensure that the DC switch on the Storage Plus stays at Off status at the same time. Then unplug the terminal connected to the inverter from PV panels, and connect it to the Input terminal of Storage Plus.



Chart 5.10

Step 2: Connect the output of Storage Plus to the input of your PV inverter, as the diagram show:



Chart 5.11

Step3: Connect the battery to Storage Plus, you can refer to 5.4.7 for connection of battery.



Chart 5.12

Step 4: Buckle the sensor to the residential user inlet wires, at the same time plug the AC PLUG on the Storage Plus to electricity, and finally the entire system is ready to work smoothly.



Chart 5.13

5.4 System Electrical Connection

5.4.1 Storage Plus AC power supply connection

Preparations before connection:

A measure the grid voltage and frequency and make sure the voltage is 220/230Vac , the frequency is 50/60Hz in single phase.

B Connect the AC cable with safety regulation to the AC PLUG section.



Chart 5.14



Chart 5.15

5.4.2 Storage Plus PV Connection

1. Insure correct polarity before connecting the PV input. Reverse positive or negative polarities may cause unrecoverable damage. Insure that the short-current of PV string should not exceed the max input current of the Storage Plus.
2. The diagrams below show the PV connection way. Attention, the connectors (male and female connectors)are in paired. The connectors for PV arrays and inverters are H4 or MC4 standard.



Chart 5.16



Chart 5.17

3. The maximum input current value as the table shows below:

Type	Max PV input current	Max output current to inverter
Growatt SP 2000	30A	30A

Remark: We suggest you use the cable ≥4mm^2/12 AWG to connect.

5.4.3 Connection of Temperature detection for Lead-acid battery

1. Please confirm the battery type before connection. For the installation of Lead-acid battery, you need to use the temperature sensor, while lithium battery can connect direct to BMS.
2. Open the cover plate at the terminal before connection.



Chart 5.18

As pictured above, with the top cap open, take the white 2PIN female plug of battery temperature sensor through the cover plate, and insert it into the 2PIN male plug marked with NTC/SENSOR.

Remark: temperature detection wire (1.5m in length) specifications: UL1332 26 AWG TS 200℃ 300V.

5.4.4 Installation of sensor connection

There is a current transformer in sp 2000 monitoring the power consumption situation of residential users. The current transformer should be installed at the wire-inlet side.



Chart 5.19

Installation of Sensor for lead-acid battery as the diagram above.

When it is unnecessary to install the NTC battery, please insert the RJ45 plug of the sensor into the section marked with the words: NTC/SENSOR.



Chart 5.20

Remark: Sensor lead wire (5m in length) specification: RJ45, standard LAN line (one end with 8P modular plug, the other connected with sensor). But if the length is not enough, customer can add cable, so the length can be increased to 15m, the operation is as follow chart:



Chart 5.21

During the actual operation, please pay attention to the installation of current transformer as the diagram shows below:



Chart 5.22

As illustrated above, open the current transformer and you can see an arrow labeled on it indicating the direction of current. Put the live wire among the under-detection wires onto the current transformer. After latching the current transformer, the installation has been finished.

Notice: the direction (from K to L) of the arrow on the current transformer is corresponding to the direction of the current in live wire from load to the grid.

5.4.5 Connection of LAN Monitoring

If you need to monitor the Storage Plus via LAN, the installation steps are as follow:

1. Make sure the cover plate is removed.
2. Make the LAN line go through the second hole of the cover plate, and insert it into the plug under the labeled words LAN/RS485.



Chart 5.23

Remark: LAN line specification: RJ45, standard LAN line (with 8P modular plug at both ends).

5.4.6 Battery Power Connection

1. Insure the polarity is correct before connecting to battery input.
2. Open the cover plate at the terminal before connection.
3. Battery connection area located on the right side above the bottom plate as the diagram below:



Chart 5.24

Electrical connection of battery is shown as below:



Chart 5.25

According to the battery power, you should use Cable AWG8 or Cable 2*AWG10 to connect. And the length of this cable not more than 1.5m.

5.4.7 Connection with BMS system of Lithium Battery

When connect to lithium battery with a BMS system, please connect the battery BMS system to the COM of the Storage Plus via LAN line. Installation steps are as follow:

1. Firstly please confirm the distance between battery and Storage Plus, and purchase a LAN line in spare length, both ends of LAN are RJ45 terminals.
2. Insure the battery is in a dormant state before connection between Storage Plus and lithium battery.
3. Severally plug one RJ45 modular plug of the LAN line(RJ45 Standard LAN) to the Storage Plus.



Chart 5.26

5.4.8 Connection to Lead-acid Battery

Before connection to the lead-acid battery, please confirm the items below:

1. Main output voltage of lead-acid battery is 48V.
2. Total Capacity of lead-acid battery is no less than 80AH.
3. The installation cabinet of lead-acid is under ventilation condition.

Installation of lead-acid battery is shown as follow:



Chart 5.27

Step 1. Connect to the positive pole and negative pole of lead-acid battery cabinet(we suggest you use terminals like KST, BCMC2S of the kinds)sectional area of connected cable should be more than 8mm^2。

Step 2. Paste the NTC conductor used to detect ambient temperature of lead-acid battery onto the top of lead-acid battery cabinet.

After Accomplishing the two steps above, the connection of lead-acid battery is completed.

5.4.9 recommendatory connection: Connection Between SP2000 and Darfon Lithium Battery

Darfon is qualified lithium battery manufacturer of Growatt. As to the detailed operation of Darfon Lithium battery you can refer to Accessory 1, EIA02 user manual. Connection between SP 2000 and Darfon battery as follow:

1. Firstly insure the' status' LED indicator of lithium battery is in the extinguished status.
2. Prepare to connect with cable and LAN of the Battery, the sectional area of the cable should be more than 8mm^2, you are advised to use the KST BCMC2S plugs of connectors to battery and we require the RJ45 modular plug LAN line.
3. Connection of terminals is shown as below:



Chart 5.28

After all connections done , gently press the 'wake up' KEY of the lithium battery. While the 'status' LED indicator turns green, the battery starts working.

5.5 Grounding

PV Array Grounding

Grounding conductor of PV panel brackets must be firmly connected to earth at both PV array side and inverter side. The sectional area of grounding conductor should be equal to the sectional area of DC grounding conductor.

DC Grounding

Select the DC Grounding mode according to the local standard and use the PV grounding terminal box and DC Grounding wires of the same specification.

Grounding Device

If the positive pole or the negative pole of PV array need to be grounded in the PV system, the inverter output should be insulated by Isolation Transformer.

Connection as below:



Chart 5.29

6 Commissioning

6.1 Commissioning of Energy storage machine



Chart 6.1

1) Connect the input side terminal to PV modules.
2) Connect the output side terminal to PV inverters.
3) Connect the AC plug to grid.
4) If the energy storage machine's input voltage is 230±15%V and meanwhile fail to connect battery.LCD will display information as follows:
   - storage plus ➡ standby ➡ status information.
   - LCD will disply "bat voltage low" status.
   - Please check all the information on the LCD, through knocking you'll see various parameters
5) Turn off DC switch and connect to battery, turn on inverter's DC switch, both energy storage machine and inverter will operate automatically.
6) In normal contra variant mode, LCD would scroll display the state information, LED area would display the current state. The green LED light would turn on constantly in the same time.
7) Finish commissioning.

6.2 Operation modes

6.2.1 Normal charge mode

When daytime with abundant sunlight, energy storage machine can work in normal charge mode.

- When DC voltage is more than 150V,The energy storage machine detected the inverter has countercurrent power flow to the grid, The machine would transform the redundant energy exist in PV panel into electric and store into the battery, the green LED light will be lighten at the moment
- When DC voltage is less than 130V, The energy storage machine will quit the normal charge mode automatically and turn into standby status, until the PV voltage up to grade again and there is countercurrent power, the energy storage machine would turn into normal charge mode automatically.
- When DC voltage is more than 150V,while The energy storage machine fail to detect the inverter has countercurrent power flow to the grid, the energy storage machine won't start charge, and in the standby status.

NOTICE: Must connect to AC, or the energy storage machine won't start up.

6.2.2 Normal discharge mode

When the solar energy is shortage at night, though battery capacity is completely over plus, then the energy storage machine can work in normal discharge mode.

- When DC input voltage is less than 100V, The energy storage machine detected the inverter has downstream power flow from grid to load, the energy storage machine will extract energy from the energy storage battery side, and provide it to inverter as the photovoltaic panel's mode, meanwhile the inverter transform the DC current into AC current and feed it to load, the green LED light will be lighten at the moment.
- When DC voltage is less than 100V, The energy storage machine fail to detect the inverter exist downstream power flow from grid to load, then the energy storage machine will be standby state, and won't provide any power.
- When DC voltage is more than 120V,the energy storage machine will transform discharge state to standby state.

NOTICE: Must connect to AC, or the energy storage machine won't start up.

6.2.3 Fault mode

The energy storage machine's intelligent control system could monitoring and adjustment system's status continuously, when energy storage machine monitoring anything unexpected happen, such as system fault or machine fault ,the LCD will display the fault information, in fault mode, the LED light will be lighten.

NOTICE:

a）The detail's fault information please refer to 9.1

b）Some fault information is in order to remind users that might have some faults occurred in inverter side.

6.2.4 Shutdown mode

Under normally circumstances, the energy storage machine will be standby state all the time, If need energy storage machine to stop working, you must disconnect the machine's providing, then the energy storage machine will turn into shutdown mode automatically.

NOTICE:
If the photovoltaic array PV side still have voltage, must dial the DC SWITCH to off status, to turn off the PV input.

6.3 LED AND LCD'S DISPLAY

6.3.1 LED display area



Chart 6.2

location	description
A	represent photovoltaic panel
B	storage system(include the machine and battery)
C	home use load contracted notation
D	PV inverter
E	Power grid
F	each of power direction indicating arrow

6.3.2 Each status' LED light indication schematic

State one: before dawn, The energy stored in the battery is ran out, then the amount of home use load energy needed by the power grid to supply, the whole LED light operate indication schematic as follow (for example):



Chart 6.3

State two, in the morning and the sun rises, the PV panel's energy increase gradually, the photovoltaic panel start to supply energy to users through the inverter, lead to get power from grid less and less(or when the battery is full in the daytime, while solar energy is insufficient), the whole LED light operate indication schematic as follow:

State three: with the sunlight become stronger and stronger, the PV panel's energy increase gradually, the power of the photovoltaic panel create not only satisfy the home use load, but also feed the power to grid, The SP start at the moment, and charge to the battery, decrease the countercurrent, the whole LED light operate indication schematic as follow:



Chart 6.4

State four: with the sunlight become more stronger and stronger, the PV panel's energy increase gradually, the power of the photovoltaic panel creates not only satisfy the home use load and SP, but also feed the redundant power to grid, the whole LED light operate indication schematic as follow:



Chart 6.5



Chart 6.6

State six: The same situation as state two, with time goes by, the sun goes down to the hill slowly, the power of the photovoltaic panel creates can't satisfy the home use load ever, then the power grid would supplement the lack of the part. the whole LED light operate indication schematic as follow:



Chart 6.7

State seven: when the sun goes down to hill completely, the photovoltaic panel doesn't create power anymore,The SP has detected the condition of the load, and then restart discharge mode to satisfy home use's load, the whole LED light operate indication schematic as follow:



Chart 6.8

State eight: At night, when the household electricity increase, exceed the power of the SP create, in order to satisfy the home use's load ,the power grid will replenish the energy of the SP's output insufficient, the whole LED light operate indication schematic as follow:



Chart 6.9

6.3.3 LCD display column

LCD display column is used to show the current state, basic information and fault information. Also include se the language, COM address and time. On default condition will take turns to display the information.



Chart 6.10

location	description
A	display the SP's state, include(standby, charging……)
B	Various of information display column
C	State indication light, used to tell the normal or fault state.

The A line's concluding information as follow:

1、 Standby state: The machine is in standby state, not conduct charge-discharge operation.

2、 Charging state: The machine is in PV to recharge the battery's state.

3、 Discharging state： The machine is in battery discharge to inverter's state.

4、 Warning state: The machine has warning information, but doesn't affect the normal operation of the machine.

5、 Fault state ： The machine has fault information, the machine will be in stopped operational protection state.

6、 Programming state： The machine is in burn program's state.

The B line's concluding information as follow:

In normal, it will paging automatically, when receive the sound control's command, the order of the paging information as follow:

1． No sound control command:

Battery Info → Vpv and Vac → Ppv → Pcharge → Pdischarge → Vbuckout → Ec_today → Ed_today → PtoUser → PtoGrid → BatteryInfo（every page stops 5s）

2. single sound control command

BatteryInfo → VpvandVac → Ppv → Pcharge → Pdischarge → Vbuckout → Ec_today → Ed_today → PtoUser → PtoGrid → Vbus → SN → Model → FWVersion → ComMode → ComAddr → SystemTime → BlueTooth_Zigbee_Wifi → SetWindow → BatteryInfo

3. In the following pages knock on twice in a row,current page will remain two minutes BatteryInfo/VpvandVac/Ppv/Pcharge/Pdischarge/Vbuckout/Ec_today/Ed_today/PtoUser/PtoGrid/Vbus/SN/Model/FWVersion/ComMode/ComAddr/SystemTime/BlueTooth_Zigbee_Wifi
4. IN FWVersion page，knock on twice continuously will display Build version
5. In Set Window page，knock on twice continuously will enter the LCD setting unction：
   Set Window → knock on twice continuously →Input 123（finish entering the password, knockthree times）→language Set → ComAddr Set → ComMode Set → SystemTime Set

Accuracy of measurement

Display value and actual value may have deviations, can't be billing criteria. The Inverter measured value is used to control the parallel grid usage, not for accurate calibration.

6.4Communication

6.4.1 Use the shinebus to set the storage machine

About PlusBus software, when you needed, please download from official website. of Growatt

Before use RS232 communication, you should make sure the follow PIN1 and PIN2 are OFF:



The wiring diagram is as follows:



Chart 6.11

6.4.2 The SP's monitoring

The SP provide LAN and RS232 two kinds of interface. Users can through the following two communication solution to monitor the SP.

NOTE: these two kinds of monitoring, Can only be used by the monitor of Growatt's Shine server software provided by the company.

Scheme A :

- Through RS232 interface connect to WIFI, use computer terminal for data monitoring.

Chart 6.12

Before use WIFI communication, you should make sure the follow PIN1 or PIN2 is ON:



Scheme B :

- Through LAN interface connect to computer, use computer terminal for data monitoring.



Chart 6.13

NOTICE: the length of LAN cable is decided by users themselves according to actual situation

7 Start-up and shut down the inverter

7.1Start-up the inverter

Connect the AC circuit breaker

Insert AC PLUG,connect AC.the SP according the situation start-up model to judge and operate automatically.

7.2 Disconnect the inverter

1. Disconnect the DC circuit breaker
2. Disconnect the inverter
3. Disconnect the battery
4. Pull up AC PLUG connection
5. Waiting until LED,LCD display have gone out, the SP is shut down completely

8 Attention of the installation environment, maintenance and cleaning

Heat dissipation performance is very important when Energy storage machine work under the environment of high temperature, better heat dissipation can reduce the possibility of energy storage machine stops working. Growatt SP series storage machine without fan so belongs to natural cooling, hot air from the top of the radiator, tie-in battery, use environment for IP20, please pay attention to the temperature of the installation environment, to ensure that the battery's safety and the normal work of the machine.

If the storage machine doesn't work for overheating too cold, solve it according to the following methods

- confirm whether the radiator air duct installation is reasonable, choose the appropriate position before installation.
- If is lead-acid batteries, confirming the NTC battery is in a good installation
- confirm whether the battery temperature is too high, the battery temperature too high can also lead to energy storage machine fail to work normally, at this point, to ventilation, cooling or still handle to the battery, please.
- If temperature is low, also can appear the battery low temperature protection, the battery will start with small load in low temperature output, when after temperature back to normal can work normally, please be patient at this time
- if the temperature is too low, it is possible the battery low temperature protection rather than the output, at this time, please pay attention to the working temperature range listed in the specifications of the book

9 Fault removal

Our products are carried out with strict tests before they take out, if the operation difficulties in the process of installation, please log on to www.ginverter.com website, view the Q&A program.

When energy storage machine fault happens, please inform our company, and to provide energy storage machine related information, we will have a professional after-sales service personnel to answer you.

what You need to provide the information about the inverter including :

About the energy storage machine:

serial number

model

information about the LCD display

brief description of problems

the battery voltage

the dc input voltage

can you retell the failure problem? If you can, what kind of a situation

Did the problem happen in the past?

what’s the reason about this problem?

about The solar photovoltaic panels

The manufacturer name and model of solar photovoltaic panels

The output power of photovoltaic solar panels;

Solar photovoltaic panel output voltage;

Solar photovoltaic panels MPPT output voltage

The MPPT output current of photovoltaic solar panels;

The number of solar photovoltaic panels
about the battery
The manufacturer name and model of battery

capacity of battery

The total output voltage of the battery
the time u buy Battery and frequency u use it

9.1 System fault information list and troubleshooting suggestions

LCD display	Fault description	Fault When	SP Status	Suggestion
Error: 100	Firmware version mismatch	Firmware version mismatch	Fault	Update FW with right version
Error: 101	Communication fault	M3 cannot receive data from DSP	Fault	1. Check communication cable 2. Restart Solar Plus
BMS COM Fault	Communication fault	Communication failure between M3 and BMS	Fault	1. Check 485 cable between SP and battery 2. Check if battery is sleeping
BMS Error: xxx	BMS failure and neither charge and discharge is allowed	BMS failure and neither charge and discharge is allowed	Fault	Depend on BMS error code
Error: 116	Over current protection triggered by Trip Zone	Over-current	Fault	1. Check PV input terminals 2. Restart Solar Plus
Error: 117	Over current protected by software	Over-current	Fault	1. Restart Solar Plus
Error: 118	Over BUS-voltage protection	BUS voltage high	Fault	1. Check battery terminals when charge 2. Check dummy load when discharge
Error: 119	Communication fault	DSP cannot receive data from M3	Fault	1. Check communication cable 2. Restart Solar Plus
Error: 119	Communication	DSP cannot receive	Fault	3. Check

	fault	data from M3		communication cable 4. Restart Solar Plus
PV Voltage High	PV Voltage High	PV voltage higher than 580V for 100ms	Fault	Check PV input voltage
PV Short-circuit	PV input short-circuited	PV voltage lower than 20V and PV current higher than 5A	Fault	1. Check PV input terminals
Battery reversed	Battery terminals reversed	PV voltage lower than -10V for 100ms	Fault	1. Check battery terminals
PV Access Wrong	PV input and discharge output of Solar Plus misconnected	PV voltage lower than 20V and BUCK voltage higher than 50V and cannot be dragged down by 30s dummy load on	Fault	1. Check PV input and BUCK output terminals
PV Reversed	PV terminals reversed	PV voltage check signal is higher than 2.57V	Fault	Check PV terminals
L-N Reversed	AC terminals reversed	The voltage between N and Earth higher than 100V for 100ms	Fault	Check AC terminals
No AC	AC voltage low	AC voltage lower than 50V	Fault	Check AC voltage
NTC Open	NTC open	NTC open	Fault	Check NTC terminals
Fuse Open	Fuse Open	Vdrop on fuse higher than 10V for 200ms	Fault	Check fuse
Battery Open	Battery terminal open (only for lithium battery)	Battery voltage sampled by SP is 10V lower or higher than BMS	Fault	Check battery terminal
MPPT Trouble	MPPT Trouble	Exit discharge for no MPPT five times	Fault	Check state of PV inverter
SS Timeout	Soft start run out of time	Bus or BUCK voltage cannot get target value after 2min soft start	Fault	Check voltage sample of BUS or BUCK
BMS Error: xxx	BMS failure and either charge or discharge is allowed	BMS failure and either charge or discharge is allowed	Warning	Depend on BMS error code
Bat voltage low	Battery voltage low	Battery voltage lower than 44V for 100ms	Warning	Check battery terminals

Bat T Outrange	Battery temperature out of specified range for charge or discharge	Battery temperature out of specified range for charge or discharge(range is settable)	Warning	Check battery temperature
No AC power flow	No AC power flow	Power flow between grid and user lower than 50W for 10 minutes	Warning	Check if AC current sensor is connected well

10 Manufacturer Warranty

This certificate represents a 5 year warranty for the Growatt products listed below. Possession of this certificate validates a standard factory warranty of 5 years from the date of purchase.

Warranted products

This warranty is applicable solely to the following products:
Growatt SP 2000.

Limited Product Warranty

(Applicable under normal application, installation, use and service conditions)Growatt warrants the above listed products to be free from defects and/or failure specified for a period not exceeding five (5) years from the date of sale as shown in the Proof of Purchase to the Original purchaser.

The warranties described in these “Limited Warranty” are exclusive and are expressly in lieu of and exclude all other warranties, whether written, oral, expresser implied, including but not limited to, warranties of merchantability and of fitness for a particular purpose, use ,or application, and all other obligations or liabilities on the part of GROWATT , unless such other obligations or liabilities are expressly agreed to it in writing signed and approved by GROWATT , GROWATT shall have no responsibility or liability whatsoever for damage or injury to persons or property, or for other loss or injury resulting from any cause whatsoever arising out of or related to the modules, including, without limitation, any defects in the modules or from use or installation. Under no circumstances shall GROWATT be liable for incidental, consequential or special damages howsoever caused; loss of use, loss of production, loss of revenues are therefore specifically and without limitation excluded to the extent legally permissible, GROWATT ’s aggregate liability, if any, in damages or otherwise, shall not exceed the invoice as paid by the customer.

The “**Limited Product Warranty**” described above shall not apply to, and Growatt shall have no obligation of any kind whatsoever with respect to, any machine which has been subjected to:

- Misuse, abuse, neglect or accident;
- Alteration, improper installation or application;
- Unauthorized modification or attempted repairs;
- Insufficient ventilation of the product;
- Transport damage;
- Breaking of the original manufacturers seal;

- Non-observance of Growatt installation and maintenance instruction;
- Failure to observe the applicable safety regulations
- Power failure surges, lighting, flood, fire, exposure to incorrect use, negligence, accident, force majeure, explosion, terrorist act, vandalism or damage caused by incorrect installation, modification or extreme weather conditions or other circumstances not reasonably attributable to Growatt.

The warranty shall also cease to apply if the product cannot be correctly identified as the product of Growatt. Warranty claims will not be honored if the type of serial number on the machines have been altered, removed or rendered illegible.

Liability

The liability of Growatt in respect of any defects in its machines shall be limited to compliance with the obligations as stated in these terms and conditions of warranty. Maximum liability shall be limited to the sale price of the product. Growatt shall accept no liability for loss of profit, resultant of indirect damage, any loss of electrical power and / or compensation of energy suppliers within the express meaning of that term.

The warranty rights as meant herein are not transferable or assignable to any third party excepting the named warranty holder.

Warranty Conditions

If a device becomes defective during the agreed Growatt factory warranty period and provided that it will not be impossible or unreasonable, the device will be, as selected by Growatt:

1、 Shipped to a Growatt service center for repair;
2、 Repaired on-site;
3、 Exchanged for a replacement device of equivalent value according to model and age.

The warranty shall not cover transportation costs in connection with the return of defective modules. The cost of the installation or reinstallation of the modules shall also be expressly excluded as are all other related logistical and process costs incurred by all parties in relation to this warranty claim.

11 Decommissioning

11.1 Dismantling the energy storage

1. Disconnect the storage machine such as mentioned in section 7。
2. Disconnect the upper cable of the storage machine

watch out the SP's shell heat and prevent to scald

wait 20 minutes until the SP cooling and then to disassembly!

3. Unscrew all the connecting cable
4. Unscrew the radiator and wall-mounted's anchor screw and then take down the machine from wall

11.2 Packing the energy storage machine

Usually placed energy storage machine in the packing box with tape sealing, If the energy storage machine cannot reoccupy, You can choose a cheap carton for packaging. Carton requirements must meet the size of the inverter and can support energy storage machine overall weight.

11.3 Storing energy storage machine

Store the energy storage machine in a dry place where ambient temperatures are always between -25°C and +60°C

11.4 Disposing of the energy storage machine

Do not dispose of energy storage machine together with household waste. Please accordance with the disposal regulations for electronic waste which apply at the installation site at that time. Ensure that the old unit and, where applicable, any accessories are disposed of in a proper manner

12 Product specification

12.1 Growatt SP series energy storage machine product specification

Model / Specification	**Growatt-SP2000**
PV array input and output data:	
Input PV voltage range	100V~580VDC
Max input current from PV array	30A *1
Max power	2000W
Full load input DC voltage range	200V~450VDC
output voltage range	150V~500VDC
Rated output voltage(mpp voltage for inverter)	380V
Max current to SP2000	10A
Rated output current	5.3A

Number of independent MPP trackers/strings per MPP tracker	1/3
Output strings from SP2000 to inverter	3
Battery data	
Battery voltage range	44V~58VDC
Max charging voltage	57VDC/58VDC*2
Max charging current	≤45A
Max discharging current	≤45A
Type of battery	Lead-acid battery/Lithium battery)
Battery capacity	90~200AH
Deep of discharge	50% DOD/80% DOD*3
daily night electricity consumption	2~9KWH
Others:	
Maximum efficiency	94.0%
Input grid voltage range（single phase）	230Vac±15%
Operating temperature range：	0℃~+40℃
Altitude	2000m
Cooling concept	Natural
Environmental Protection Rating	IP20 (indoor used)
Noise emission (typical)	≤40dB
Certificates and approvals：	CE
over voltage protection	yes
Low voltage protection	yes
over current protection	yes
over load protection	yes
Output current short protection	yes
PV and battery reverse polarity protection	yes
Warranty：	(Five years)
Connection for PV array side	H4/MC4(opt)

Connection for battery	Screw terminal
communication：	RS232/LAN/WIFI（opt）
display	LED+LCD
Dimensions(W/H/D)	520/340/160
Weight	15kg

12.2 DC input terminal parameter

H4 specification:

	2.5mm²/14AWG	**4mm²/12 AWG**	**6mm²/10 AWG**	**10mm²/8AWG**
Rated current (90 ℃ environment)	32A	40A	44A	65A
Nominal system voltage	600V DC(UL) 600V DC(TUV)			
Contact resistance	0.25mΩ（model）			
Protection grade	IP68			

Socket contact materials	Copper, tin
Insulation materials	Thermoplastics UL94 V-0
Ambient temperature range	-40℃ to +90℃
Wire stripping length	7.0mm(9/32)
Cable casing diameter	4.5 to 7.8mm(3/16: to 5/16”)

12.3 Torque

Upper cover screws	1.3Nm(10.8 1bf.in)
Shell and RS232screws	0.7Nm(6.2 1bf.in)
Dc connector	1.8Nm(16.0 1bf.in)
M6 screwdriver	2Nm(18 1bf.in)
Grounding screw	2Nm(18 1bf.in)

12.4 Appendix

The following chart is the energy storage machine optional appendix list, if there is a need please contact the Growatt New Energy Technology Co., Ltd or dealer orders.

name	**description**	**GROWATT P/N**
Shine Webbox	Communication data record	MR00.0001700
Shine Vision receiver	Receptor of Communication data record	MR00.0000201
Shine Vision emitter	Launchers of Communication data record	MR00.0000601

Zigbee	COM interface	200.0007000
Wi-Fi	COM interface	MR00.0001400
Bluetooth	COM interface	MR00.0002200

13 Certificate

Growatt SP2000 apply within the scope of the world, So the inverter have to satisfy different countries and regions of different safety standards

model	Certificate
Growatt SP2000	CE,SAA,RCM

14 Contact

If you have technical problems about our products, contact the Growatt Service line or dealer. We need the following information in order to provide you with the necessary assistance:

1. Energy storage machine Serial number
2. Energy storage machine module information
3. Energy storage machine communication mode
4. Energy storage machine fault information code
5. Energy storage machine Display content
6. The manufacturer and model of the battery
7. Battery capacity and connection mode

Growatt New Energy Technology Co.,Ltd
Building B, Jiayu Industrial Zone, 28 Guangming Road, Longteng Community, Shiyan, Baoan District, Shenzhen
T： + 86 755 2951 5888
F： + 86 755 2747 2131
E： service@ginverter.com